10 TIPS FOR EFFECTIVE RADON PREVENTION

TH NOVEMBER 2019



ALWAYS CHECK WHETHER RADON
PROTECTIVE MEASURES ARE REQUIRED
OR RECOMMENDED PRIOR TO STARTING
A PROJECT



CHOOSE A MATERIAL
THAT IS EFFECTIVE
FOR RADON
PROTECTION

FOOTPRINT OF THE BUILDING IS PROTECTED

DOUBLE CHECK
ALL JOINTS AND
SEALS

CONSIDER THE EFFECTS
OF ENERGY SAVING
DESIGN

6 USE A PROFESSIONAL TO DESIGN & INSTALL RADON PROTECTION



ENSURE THAT THE SYSTEM IS NOT DAMAGED AFTER INSTALLATION

IF NECESSARY,
ACTIVATE SUB SLAB
DEPRESSURISATION
SYSTEMS

UPON COMPLETION,
CARRY OUT A RADON
TEST IN THE BUILDING



INFORM THE BUILDING OWNER OF THE RADON PROTECTIVE MEASURES THAT HAVE BEEN INSTALLED



Visit www.radoneurope.org to see what is happening in your country

